



SITE INFORMATION

1st Stage of grinding! (pre-cut and seal) needs to occur 5 – 9 days after the pour. This must be completed before any other construction work begins. (Based on 100m² – allow 2 days).

2nd Stage, we return at plaster stage, prior to skirting boards and joinery being fitted, also before stairs if possible this is to minimise any risk of damage, ensure the best finish and is a cost saving exercise for the client, as additional time may be required to work around joinery etc. (Based on 100m²– allow 3 days).

3rd Stage – Prior to occupation wash the floor with (low PH cleaner) as specified on our maintenance sheets.

Just a reminder, it is imperative that plastic is NOT used after 2nd stage to cover the slab. Plastic will cause the concrete to "sweat" which can cause blotching. Layers of carpet OUTSIDE main traffic areas, signs acting as a reminder that the slab is going to be the finished floor and breathable materials such as cloth painter's drop sheets are recommended.

Ring Jorge for advice – 0403 296 238 at any stage.

Naturally all jobs are different. Polished Concrete requires a lot more work than grind and seal, which is normally completed closer to the end of the job.

Adelaide Custom Concrete